

TECHNICAL DATA SHEET



Ver 04 - PAL1CDPM 28.10.24

1 COAT-DPM

DUAL CHAMBER 1 COAT DAMP-PROOF MEMBRANE

- RECEIVES SMOOTHING COMPOUNDS IN 4-5 HOURS
- FULLY CURES WITHIN 8-11 HOURS
- REPAIRS CRACKS & SEAMS IN DAMAGED FLOORS
- SUITABLE FOR USE WITH UNDERFLOOR HEATING SYSTEMS
- SUITABLE FOR INTERIOR AND EXTERIOR APPLICATIONS

The Professionals Choice 1. Coat DPN DAMP-PROOF MEMBRANE FOR FLOORING PREPARATION • Easy to apply • High durability 5.0kgs

TECHNICAL SUMMARY

UNIT SIZES	5kg
POT-LIFE	Approximately 1 hour at 20°C
INITIAL CURE TIME	5-6 hrs @ 20°C or 15-20 hrs @ 10°C
DRY FILM THICKNESS	250-300 microns
SERVICE TEMPERATURE RANGE	-20°C to +80°C
CHEMICAL RESISTANCE	Good
WATER RESISTANCE	Excellent

PALACE 1 COAT-DPM

Is a single coat application, two component surface damp proof membrane and vapour suppressant supplied in an easy to mix Dual Chamber pack based upon a solvent free epoxy resin formulation, suitable for interior and exterior applications.

8-11 HRS

crons +80°C Good ellent

REPAIRS CRACKS & SEAMS IN DAMAGED FLOORS





EN ISO 14001



PALACE CHEMICALS LTD

SPEKE HALL INDUSTRIAL ESTATE
SPEKE LIVERPOOL L24 1YA
TEL: 0151 486 6101 - FAX: 0151 448 1982
E-MAIL: SALES@PALACECHEMICALS.CO.UK

1 COAT-DPM

Ready Mixed Waterproof Fixing & Grouting



DESCRIPTION

PALACE 1-COAT DPM can be laid over a wide range of substrates including concrete, sand/cement screeds, anhydrite and calcium sulphate screeds. PALACE 1-COAT DPM is ideal for use as a damp proof membrane where the residual moisture content in a new or existing screed is up to 98% relative humidity (RH). PALACE 1-COAT DPM can also be used to protect screeds laid on damp floors where no pre-existing damp proof membrane is in place or where the structural damp proof membrane is ineffective. Once cured, PALACE 1-COAT DPM produces a membrane which can accommodate hygrometer readings up to 98% RH on cement-based screeds & still demonstrate bond strength issues. PALACE 1-COAT DPM has good resistance to water, grease, oil, dilute mineral and organic acids.

SURFACE PREPARATION

All surfaces must be sound, clean and free from grease, oil, dirt or other contaminants. Any release agents and any wax/resin based concrete curing compounds should be removed prior to application. Existing screed or levelling compounds which are not resistant to moisture should be removed prior to application of the membrane. Where any doubt exists, a trial adhesion test is recommended. Always pre-check the floor using a suitable moisture meter to determine that Relative Humidity (RH) readings are less than 98% RH. PALACE 1-COAT DPM is suitable for use with underfloor heating systems, however the surface temperature should not exceed 27°C in accordance with BS 8203 and BS 5325. When laying PALACE 1-COAT **DPM** over a new underfloor heated screed, the heating system must be turned off 48 hours before application. Any existing floor screeds, coatings or adhesive residues that are not moisture tolerant must be removed prior to application and any incompatible curing agents and surface contaminants may require mechanical techniques i.e. Scarification or 'shot blasting' to remove them whilst it will also be necessary to shot blast highly polished substrates. Residual dust should be removed by industrial vacuuming techniques. Rough or uneven substrates can be pre-smoothed with PALACE FLOW-LEVEL prior to the application of PALACE 1-COAT DPM.

Movement Joints: Any joints in the floor such as movement joints, must not be bridged using **PALACE 1-COAT DPM** since they will require treatment using a flexible impervious jointing system and be carried through to the floor finish.

MIX PREPARATION

Before mixing allow the 'dual-chamber' pack to attain room temperature, these are typically ambient temperatures of +10°c to +25°c as lower temperatures will raise the viscosity of the product and higher temperatures will result in a significant reduction in pot life. Puncture through the centre of the lid and through the centre of the floor of the upper chamber using a long screw driver or similar, then allow the contents of the upper chamber to drain into the lower chamber. Remove the upper chamber and mix the two components in the lower using a slow speed paddle stirrer to mix the resin and hardener. Mix both components for at least 2 minutes with a drill or similar, until an even colour is achieved. Always mix full container quantities in order to maintain mix proportions.

APPLICATION METHOD

Once mixed, PALACE 1-COAT DPM must be poured onto the floor immediately. If mixed and left in the container for a prolonged period of time, the working time of will be significantly reduced. Apply PALACE 1-COAT DPM onto the prepared substrate in an even coat using a 2mm x 5mm V profiled notch trowel. Whilst the coating is still wet the serration marks should be smoothed using a short pile paint roller charged with PALACE 1-COAT DPM. Ensuring that the applied coating is continuous and free from pin holes. The application thickness should not be less than 250-350 microns. When applying PALACE 1-COAT DPM to a substrate where a structural damp proof membrane is not present or is ineffective, this product must be applied as a 2-coat system. PALACE 1-COAT DPM should not be applied when ambient or substrate temperature is less than 5°C or likely to remain so for the following 24 hours.

COVERAGE

Approximately 2-2.5m²/kg depending on application and substrate conditions to give a finished thickness of approximately 250-300 microns.

NOTE: It is essential that the applied **PALACE 1-COAT DPM** achieves a 100% continuous film free from pinholes, or gaps, which can occur on porous screeds for example, in this case an additional application, may be necessary.

STORAGE AND PACKAGING

Keep this pack sealed and in temperatures between +5°C and 30°C. Always ensure good stock rotation. Storage life 6 months under normal warehouse conditions. Available in 5kg 'Dual-Chamber' Buckets.









1 COAT-DPM

Ready Mixed Waterproof Fixing & Grouting



CURING TIME

Under ambient conditions, **PALACE 1-COAT DPM** is ready to receive a smoothing compound as soon as 4 - 5 hours after application. If the applied DPM is still very tacky, this indicates that the DPM has not fully cured and additional curing time should be allowed before covering with a levelling screed.

LIEA	I THE	AND	CA	FETY
ПЕА	LIN	AND	3A	FEIT

Care should be taken to avoid skin/eye contact. Wear gloves and protective clothing. Harmful if taken internally. Keep containers properly closed when not in use. Adequately ventilate the working areas. Guard against naked lights and smoking. A complete PALACE material safety data sheet is available on request or online at www.palacechemicals.co.uk

QUALITY AND ENVIRONMENT

All Palace Chemicals products are manufactured under a BSI accredited ISO 9001:2015 Quality Management System, along with an ISO 14001 Environmental Management system continually working to reduce our carbon footprint.

TECHNICAL ADVISORY SERVICE

Should more specific technical information be required, contact the Palace Technical helpline on: **0151 486 6101.**

For a Technical Specification and quantity requirements, visit our 'TilingSpecifier' on the Palace website at:

http://www.palacechemicals.co.uk

DISCLAIMER

The information provided by this Technical data sheet is given in good faith and is to the best of our current knowledge true and accurate. Our products are guaranteed against defective materials and manufacture and will be replaced or money refunded if the goods do not comply with our promotional literature. We cannot however accept responsibility arising from the application or use of our products because we have no direct or control over where and how our products are stored and used. All products are sold and guaranteed subject to our terms and conditions of sale, copies of which may be obtained on request.

	1
TECHNICAL SUMMARY	
UNIT SIZES	5kg
POT-LIFE	Approximately 1 hour at 20°C
INITIAL CURE TIME	5-6 hrs @20°c or 15-20 hrs @ 10°C
DRY FILM THICKNESS	250-300 microns
SERVICE TEMPERATURE RANGE	-20°C to +80°C
CHEMICAL RESISTANCE	Good
WATER RESISTANCE	Excellent







