

TECHNICAL DATA SHEET



Ver 05 - PALFF 28.10.24

FAST-FLEX

FAST SETTING FLOOR LEVELLING COMPOUND

- EXCELLENT LEVELLING & FLOW FOR SUPER SMOOTH FINISH
- HIGH EARLY STRENGTH > FOOT TRAFFIC AFTER 3 HOURS
- CAN BE LAID FROM 2-30MM BED DEPTH
- IDEAL FOR USE WITH UNDERFLOOR HEATING SYSTEMS
- RECEIVES TILES > 4 HOURS & FLOOR COVERING > 24 HOURS

TECHNICAL SUMMARY

UNIT SIZES	20kg
COLOURS	Grey
FOOT TRAFFIC	180 minutes
READY FOR TILING	4 Hours for a 5mm layer
WORKING TIME @ 20°C	20 - 30 min
INITIAL SET TIME	60 minutes
APPLICATION TEMPERATURES	>5°C and <30°C
	1. 1.4.41

* More information can be found within data sheet



PALACE FAST-FLEX

Is a polymer-modified, cement-based, protein-free, subfloor smoothing underlayment, giving a consistently level screed up to 30mm thick. FAST-FLEX will give improved adhesion to all types of substrate and provide enhanced abrasion and point-load resistance. This product is not suitable for external application.

FOOT TRAFFIC

3 HOURS

SUPER SMOOTH FINISH





EN ISO 14001



SPEKE HALL INDUSTRIAL ESTATE
SPEKE LIVERPOOL L24 1YA
TEL: 0151 486 6101 - FAX: 0151 448 1982
E-MAIL: SALES@PALACECHEMICALS.CO.UK

Fast Setting Floor Levelling Compound



DESCRIPTION

PALACE FAST-FLEX is a polymer-modified, cement-based, protein-free, sub-floor smoothing underlayment, giving a consistently level screed up to 30mm thick. PALACE FAST-FLEX incorporates specially blended cements, graded sands, built-in polymer, anti-shrink agents and organic super-plasticisers, which when mixed with water give the ideal properties for application over a comprehensive range of floor surfaces such as tamped or worn concrete and sand/cement floor screeds, plywood and dense impermeable surfaces. It is also suitable for heated subfloors. PALACE FAST-FLEX will give improved adhesion to all types of substrate and provide enhanced abrasion and point-load resistance. This product is not suitable for external application.

SURFACE PREPARATION

The receiving floor surface must be hard, sound and free from grease, dust, floor polish, laitance and loose deleterious materials such as worn surface coatings & plaster. Any adhesive & coatings residues must first be tested to determine if they are "moisture sensitive" and then removed if necessary. Prior to laying PALACE FAST-FLEX, the base concrete or sand/cement screed should be tested to confirm that it has had sufficient time to dry out to reach a consistent moisture reading of <75% R.H. (< 3.0% residual moisture content) - tested as per BS 8203:2017 - Annex B. Where it is not known whether an effective structural DPM is in place, or where the moisture test results show values in excess of 75% R.H (or > 3.0% residual moisture content), then a liquid damp-proof membrane such as moisture suppressant PALACE 1-COAT **DPM** should be applied onto the prepared concrete subbase, before it is over-laid with. PALACE FAST-FLEX.

Although **PALACE FAST-FLEX** will bond readily to most solid sub-floors, the application of a primer on highly porous surfaces will assist with maximising flow time & adhesion strength. **PALACE TILERS MULTI-PRIME** diluted 1:3 parts water which can be used for this purpose. Highly porous substrates may need a pre-coat of primer at 3 parts water mixed with 1-part primer (allowed to completely dry) and then a second coat diluted 1 part water to 1 part primer before applying the levelling underlayment.

Note: on very absorbent substrates a third coat may be required diluted 1-part water to 1-part primer. Anhydrite Screed (Calcium Sulphate) based floors are being over-laid, the application of two coats of **PALACE TILERS MULTI-PRIME**will be necessary to form a barrier & avoid any adverse interaction between the cement-based **PALACE FAST-FLEX** and the gypsum based anhydrite screed beneath it.

SPECIFIC SUBSTRATE PREPARATION

Although PALACE FAST-FLEX will bond readily to most solid sub-floors, the application of a primer on highly porous surfaces such as PALACE TILERS MULTI-PRIME diluted 1:3 will significantly reduce the risk of pin holes in the level finish whilst also maximising flow time & adhesion strength, also where Anhydrite Screed (Calcium Sulphate) based floors are being over-laid, the application of two coats of PALACE TILERS MULTI-PRIME will be necessary to form a barrier & avoid any adverse interaction between the cement-based PALACE FAST-FLEX and the gypsumbased screed beneath it. (Consult PALACE TILERS MULTI-PRIME tech data sheet).

*ANHYDRITE [CALCIUM SULPHATE] BASED SCREEDS

Mechanically remove any loose material / laitance to give a clean, dry, solid dust-free surface prior to the application of PALACE TILERS MULTI-PRIME (first cost diluted 1 to 1 then 2nd coat neat) to ensure a protective barrier is established. Drying times of this class of screed can be at a rate of 1mm screed depth per day (2mm per day is > 40mm deep). Anhydrite screeds which already incorporate pre-installed underfloor heating systems can be use this heat source to reduce drying times, along with de-humidifiers operating in the room, which will also speed up the drying process. The relative humidity (%RH) test result in the subfloor should be less than 75% RH, (residual moisture content < 0.5%) however where this cannot be achieved within a manageable period of time the application of a Damp Proof Membrane (1-COAT DPM) is recommended to be applied after the TILERS MULTI-PRIME barrier preparation step (above) has already been completed.

FLOORING GRADE ASPHALT

New asphalt must be left for a minimum of 7 days and degreased to remove surface bloom. If cracks are visible repair will be necessary to give a strong subfloor. Check the floor is in good condition and that there are no signs of de-bonding and/or hollowness. Recently asphalted floors that are smooth & impermeable will benefit from a slurry coat of **PALACE TILERS MULTI-PRIME** mixed 1:1 with neat cement and blinded with sand to improve the bond & key.

SAND/CEMENT SCREEDS

Recently installed sand/cement screeds must be allowed a minimum of 4 weeks to dry sufficiently. Ensure new sand/cement screed is confirmed dry via consistent moisture measurements across the whole surface. Sand/cement screeds must have a moisture reading of less than 75% relative humidity (RH) before any levelling compound can









Fast Setting Floor Levelling Compound



SAND/CEMENT SCREEDS (CONTINUED)

be applied over it. Remove any laitance from the surface mechanically and ensure that any other contaminants are cleared from the surface. ideally by a vacuum cleaner. On porous or worn screeds, prime the surface with **PALACE TILERS MULTI-PRIME** diluted as 1-part primer to 3 parts water and then allow to dry.

NEW CONCRETE

Floor slabs must be allowed at least 6 weeks drying time equivalent to 1 day per mm up to an overall depth of 50mm and 2 days per mm for anything above 50mm. Ensure new concrete is tested via consistent moisture readings across the whole surface whereby a reading of less than 75% relative humidity (RH) is advised before work can commence. Remove any laitance from the surface mechanically and ensure that oil, grease curing agents and any other friable materials are removed ideally by vacuum. If the surface is relatively porous prime the surface with **PALACE TILERS MULTI-PRIME** diluted as 1 part to 3 parts water and allow to dry.

DENSE OR POWER FLOATED CONCRETE

Ensure the surface has been allowed 7 days to cure. Ensure new concrete is confirmed dry via consistent moisture readings across the whole surface. Concrete screeds must have a reading of less than 75% relative humidity (RH) is advised before proceeding to over-lay. Remove any laitance or friable top finish from the surface mechanically whilst scoring & etching the surface before taking up all remaining dust residues by vacuum.

PLYWOOD OVERLAY (INTERNAL ONLY)

Check that plywood overlay is flooring grade compliant to EN 314:2 Class 3 Exterior before applying PALACE FAST-FLEX and ensure that new or existing boards are preconditioned to the environment in which they will be used. Plywood sheets must be a thickness of 15mm minimum & screwed to a secure, stable substrate at 150mm centres. Ensure there is sufficient ventilation beneath substrate and that the plywood has been fitted competently and will take the weight of the leveller, adhesive and the final anticipated in-use loading without any risk or sign of deflection. It should be dry and free of any contaminants, loose dust or dirt. Existing plywood showing signs of wear or abrasion will require priming with PALACE TILERS MULTI-PRIME diluted 3-parts water, to 1-part TILERS MULTI-PRIME. New, uncontaminated plywood does not require priming prior to over-laying with PALACE FAST-FLEX.

FLOORS COATED WITH A SURFACE DAMP PROOF MEMBRANE

Damp-Proof Membrane coatings such as **PALACE 1-COAT DPM** should be treated as non-absorbent substrates and applications of **PALACE FAST-FLEX** should be completed within 12 hours of the DPM being first applied (Consult **PALACE 1-COAT DPM** technical data sheet). Sand blinding the freshly applied DPM will assist with improving the bond to over-laid screeds.

UNDERFLOOR HEATING SYSTEMS

Heating wires must be securely fixed to a sound consistent substrate such as cement backer board. **PALACE FAST-FLEX** should then be applied at a thickness which allows for a clearance above the elements of no less than 5mm depth of levelling compound to ensure a smooth even finish will be attained prior to laying the finished decorative or resilient surface. Always allow at least three weeks before the heating system is switched on at the lowest setting and then brought up to operating temperature at a rate of 5°C over the following week.

Note: When applying this product over any other floor type not specified above, please consult the Palace Technical department on 0151 336 9104 for advice specific to the floor surface, board type or UFH system the product is intended to be applied over. It is not advised to apply floor leveller over any "non-standard" flooring substrate or UFH system without checking its compatibility in advance.

MIXING

PALACE FAST-FLEX floor leveller should be added to clean water in a clean container and mixed thoroughly with a power whisk fitted to an electric drill to give a smooth, lump-free, flowable & pourable levelling compound which should be applied to the intended area without delay. The recommended mixing proportions are 4.0 litres of water per 20kg sack and exceeding this recommendation will result in excess bleed and a weaker mix. The material should be mixed for a minimum of 2 minutes after the last of the powder is added ensuring the mixing head is below the surface to minimise air entrapment. Allow the mix to stand for 1 minute after which time the free-flowing screed will be ready for application directly onto the prepared substrate.

APPLICATION METHOD

Pour the freshly mixed levelling compound onto the prepared surface and use a straight edged steel float to









Fast Setting Floor Levelling Compound



APPLICATION METHOD (CONTINUED)

ensure the compound is evenly spread into all areas and corners. PALACE FAST-FLEX will readily flow across a flat surface and smooth out trowel marks for about 20 to 30 minutes before it begins to firm up. Do not allow the mixed material to stand for a prolonged period in the bucket as this will shorten its flow & open time. The use of a spiked roller will assist in removing air bubbles and achieving a consistent smooth surface finish, particularly between adjacent mixes of product. Only spike roll whilst the product is still in its fluid state, usually for about 10 minutes after initial application. The maximum total application thickness for this product is up to a depth of 20mm. In ideal conditions (20°C), it will remain flowable for 20 minutes and then. after about 3 hours, the laid screed will have reached final set sufficient to take light foot traffic. All tools & mixing equipment should be washed immediately after use with clean running water before the material reaches its initial setting time.

PRECAUTIONS

PALACE FAST-FLEX levelling underlayment is for internal use only and should not be left open & exposed to foot traffic for a prolonged period but should receive its final covering of tiles or decorative finish within 3 to 4 days after being placed. Do not mix more material than can be poured, spread & laid within its 30-minute flow time and do not re-wet part-used levelling compound, which should never be "freshened up" with further water additions, but should always be discarded once it appears to lose workability. Do not apply this product when air or ground temperatures are at or below 5°C or above 35°C or if they are likely to remain below 5°C for the first 24 hours.

COVERAGE

PALACE FAST-FLEX when applied over a smooth even non-absorbent floor at an average 3mm depth will cover at a rate of one 20kg bag per 5.0M². Adequate ventilation is essential during the drying process and any draughts or exposure to excessive heat sources must be eliminated to ensure consistent drying.

CURING & DRYING

PALACE FAST-FLEX when applied at 20°C & 65% RH under ideal site conditions will allow for a working time of up to 20 minutes and then reach initial set after 1 hour. Under the above conditions it will rapidly cure to allow light foot traffic after 3 hours and will be ready to receive tiles after 4 hours and soft flooring after 24 hours.

STORAGE AND PACKAGING

PALACE FAST-FLEX is supplied in 20kg moisture resistant bags and should have a storage life of not less than 12 months if stored in dry, un-opened and frost-free conditions.

HEALTH AND SAFETY

Always ensure that appropriate PPE is worn when mixing & applying this product to ensure protection from airborne dust and skin contact with the mixed liquid product. Wash hands after use and launder stained clothing. Do not consume food when working with this material and keep children & animals away from any possible risk of contact. A complete PALACE material safety data sheet is available on request or online at www.palacechemicals.co.uk

QUALITY AND ENVIRONMENT

All Palace Chemicals products are manufactured under a BSI accredited ISO 9001:2015 Quality Management System, along with an ISO 14001 Environmental Management system continually working to reduce our carbon footprint.

TECHNICAL ADVISORY SERVICE

Should more specific technical information be required, contact the Palace Technical helpline on: **0151 486 6101.**

For a Technical Specification and quantity requirements, visit our 'TilingSpecifier' on the Palace website at:

http://www.palacechemicals.co.uk

TECHNICAL DATA	
SPECIFICATION	BS EN 13813:2002
CLASSIFICATION	CT-C30-F7
WORKING TIME @ 20°C	20 - 30min
FLOW PROPERTIES	
(USING A 30MM X 50MM FLOW RING)	>130mm
INITIAL SET	60 mins
FOOT TRAFFIC	180 mins
READY FOR TILING	4 Hours for a 5mm layer
COMPRESSIVE STRENGTHS	1 day >7.0
(N/MM2 - TO BS EN 13892-2)	7 days >21.0
	28 days >30.0
FLEXURAL STRENGTHS	1 day >2.0
(N/MM2 - TO BS EN 13892-2)	7 days >5.0
	28 days >7.0
COVERAGE	5.0M² at 3mm depth
20KG OF FAST-FLEX POWDER MIXED WITH 4 LITRES	2.5M² at 6mm depth
OF WATER WILL COVER AS FOLLOWS	1.0M ² at 10mm depth
APPLICATION TEMPS	>5°C and <30°C
PACK SIZE	20kg









Fast Setting Floor Levelling Compound



APPROVED RECEIVING SURFACES
√ Sand / Cement screeds
√ Tile backer boards
√ Existing ceramic & stone tiles
√ Existing Vinyl tiles
√ Anhydrite screeds*
√ Concrete Slabs
√ Plywood Overlay
√ Under-floor heating
√ Flooring grade asphalt
√ Epoxy DPM
√ Moisture stable adhesives

^{*} Must be securely fixed

DISCLAIMER

The information provided by this Technical data sheet is given in good faith and is to the best of our current knowledge true and accurate. Our products are guaranteed against defective materials and manufacture and will be replaced or money refunded if the goods do not comply with our promotional literature. We cannot however accept responsibility arising from the application or use of our products because we have no direct or control over where and how our products are stored and used. All products are sold and guaranteed subject to our terms and conditions of sale, copies of which may be obtained on request.







